Specifications of ManageCube IP Guard

As of May 10 2021

	,					
Product name	ManageCube IP Guard Appliance Model					
Dimensions	W 154 mm x D 108 mm x H 32 mm					
Weight	1.03kg					
Baseboard power requirements	19V,65W DC power supply adapter					
Processor	Intel Celeron Processor					
Memory capacity	4GB					
Storage	64GB(eMMC)					
LAN interface	10 / 100 / 1000 Base × 1					
USB port	2(USB2.0), 2(USB3.0)					
Environment operating Temperature	0℃~40℃					
Other remarks	Standard 3-year warranty					
Other remarks	First-out sendback					

^{*}The specifications are subject to change without notice.

Developer / Exclusive distributor

Actworks Co., Ltd.

Fukusyoosaka Bld, 8th Floor, 1-10-14, Kyomachibori, Nishi-ku, Osaka, Japan Opening hours: Weekdays 9:00-18:00

9+81-6-6444-2550


Mail service@actworks.ne.jp https://www.actworks.ne.jp

Contact



Manage Cube IP Guard

Control accesses from computers, smartphones, tablets or via wireless LANs to office network. List unregistered devices in a network administrator list for easy setting on the browser.



Actworks Co., Ltd.

Manage Cube IP Guard

Appliance for Detection and Blocking of Unauthorized Devices

Control accesses from computers, smartphones, tablets or via wireless LANs to office network.





Detect and block unauthorized devices

- Detect accesses to office network
- Block connections
- Authorize (permanent or temporary) options are also available
- Notify specified e-mail address when detected
- VLAN setting is also available (Server version)









Manage Cube IP Guard

Appliance Model

Only to connect LAN cable

Easy web-based settings

Basic features Control accesses to office network.

Permit / Accesses to office network are available.

Ban / Accesses to office network are banned.

Temporarily permit / Accesses to office network are

available for a limited period.

Device list A list of devices detected by connecting to office network.

Also used for company's asset management.

E-mail Notify of unauthorized accesses.

notification Notify specified e-mail address when an unregistered device connects to

office network for the first time.

Management features

Back up with SQL and import the device list.

Back up with CSV and import the device list. Can be used for asset management.

IP address setting and password of ManageCube can be

changed depending on the environment.

Manage Cube IP Guard

New features

New schedule manager

Manage the schedule of access permission to office network.

•Specify by time, day, and period •10 types of schedules available

Action ID	Action name	Present	Today	Start time	End time	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Start date	End date	Note	Edit
10	Lunch time permission	Block	0	12:00	12:45		0	0	0	0	0				Permit using during lunch break	10
11	Regular time		0	09:00	17:00		0	0	0	0	0				Business hours	11
12	Work at holiday afternoon	Block		13:00	15:00	0						0				12
13	Work at weekday afternoon	Block	0	13:00	15:00		0	0	0	0	0					13
14	Work at weekday night	Block	0	18:00	22:00		0	0	0	0	0					14
15	Specified time-5	Block		13:00	21:00				0							15
16	Specified time-6	Block		13:00	17:00					0						16
17	Specified time-7	Block	0	13:00	15:00						0					17
18	Specified period		0	09:00	20:00		0	0	0	0	0		2019-10-01	2019-10-01		18
19	Specified period2	Block		08:30	19:30	0	0	0	0	0	0	0	2019-09-01	2019-09-01		19